



# FR-8 series

Return filters



## Technical Information

Housing

**Pressure: Max working** 8 bar (116 psi) (acc. to NFPA T 3.10.5.1)  
**Burst** 16 bar (232 psi) (acc. to NFPA T 3.10.5.1)

**Connection Ports:** 3/8" ÷ 1 1/4" BSP (other thread options on request)

**Materials:** Head: aluminium alloy  
Bowl and top cover: nylon  
Seal: Buna-N (FKM on request)

**By-pass:** 1,7 bar (24.6 psi)

Element

**Filter Media:** Microglass fiber 4,5 - 7 - 12 - 27  $\mu\text{m}_{(c)}$  (acc. to ISO 16889)  
Cellulose 10 - 25  $\mu\text{m}_{(c)}$  (acc. to ISO 16889)  
Wire mesh 60 - 125  $\mu\text{m}$

**Differential collapse pressure:** 10 bar (145 psi) (acc. to ISO 2941)

Filtrec elements are tested also according to ISO 2942, ISO 23181 and ISO 3968

Common

**Working temperature:** -25°C +100°C (-13°F +212°F)

**Fluid compatibility** (acc. to ISO 2943):

Full with HH-HL-HM-HV (acc. to ISO 6743/4).

For use with other fluid applications please contact Filtrec Customer Service (info@filtrec.it).

## Ordering information

MEDIA	
000	no element
G03	microglass fiber $\beta_{4,5 \mu\text{m (c)}} \geq 1000$
G06	microglass fiber $\beta_{7 \mu\text{m (c)}} \geq 1000$
G10	microglass fiber $\beta_{12 \mu\text{m (c)}} \geq 1000$
G25	microglass fiber $\beta_{27 \mu\text{m (c)}} \geq 1000$
C10	cellulose $\beta_{10 \mu\text{m (c)}} \geq 2$
C25	cellulose $\beta_{25 \mu\text{m (c)}} \geq 2$
T60	wire mesh 60 $\mu\text{m}$
T125	wire mesh 125 $\mu\text{m}$

	NOMINAL SIZE	MEDIA		SEALS	CONNECTION	AIR BREATHER	INDICATOR POSITION	INDICATOR
Filter assembly <b>FR-8</b>	<b>30</b>	<b>G10</b>	<b>B</b>	<b>B</b>	<b>B5</b>	<b>0</b>	<b>C</b>	<b>R10</b>
Filter element <b>R-1</b>	<b>30</b>	<b>G10</b>	<b>B</b>	<b>B</b>				

### SEALS

B	NBR (omit for spare element)
V	FKM

### CONNECTION

B2	3/8" BSP
B3	1/2" BSP
B4	3/4" BSP
B5	1" BSP
B6	1 1/4" BSP

For different thread options please check availability with Filtrac Customer Service.

### AIR BREATHER

0	without
10	10 $\mu\text{m}$ resin impregnated cellulose
40	40 $\mu\text{m}$ resin impregnated cellulose

### INDICATOR POSITION


0	no indicator - no hole
C	on the cover+plug

### INDICATOR




000	no indicator
<b>R2</b>	pressure switch N.O. 1,3 bar / 18,9 psi
R3	pressure switch N.C. 1,3 bar / 18,9 psi
R6	visual pressure 1,3 bar / 18,9 psi
R7	pressure vacuum gauge -1 ÷ 5 bar / -14,5 ÷ 72,5 psi
R9	pressure gauge 0 ÷ 4 bar / 0 ÷ 58 psi
<b>R10</b>	pressure gauge 0 ÷ 4 bar / 0 ÷ 58 psi

 Preferential option

# Overall dimensions



TANK MOUNTING PATTERN



## Nominal size

CODE	A	B1	B2	B3	B4	B5	D1	D2	D3	D4	H1	H2	H3	L1	M	R	WEIGHT
FR-8-10	3/8" - 1/2" - 3/4" BSP	89	25	54	55	73	68	24	67	84	79	81	23	90	M8	150	0,60 Kg
148											0,70 Kg						
FR-8-20	1/2" - 3/4" - 1" - 1 1/4" BSP	115	40	68	67	94	87	27	86	110	103	107	30	140	M8	190	1,25 Kg
FR-8-22											148						1,30 Kg
FR-8-30	3/4" - 1" - 1 1/4" BSP							40			229					310	1,45 Kg

For different thread options please contact Filtrec Customer Service.


## Pressure drop diagrams

The total Pressure Drop ( $\Delta p$ ) value is obtained by adding the  $\Delta p$  values of filter housing and filter element at the given flow rate. This ideally should not exceed 0,5 bar (7,3 psi) and should never exceed 1/3 of the set value of the by-pass valve.


### PRESSURE DROP THROUGH THE FILTER HOUSING

The Pressure Drop through the filter housing is governed by the port, not the bowl length and the oil viscosity.


### Housing FR-8-10/11



### Housing FR-8-20/22




### Housing FR-8-30



### PRESSURE DROP THROUGH THE BY-PASS VALVE

The by-pass valve is a safety device to prevent element collapse in case of differential pressure peaks due to flow peaks, cold start conditions or when the clogged element is not replaced in a timely manner.

### By-pass FR-8-10/30




## Pressure drop diagrams


### PRESSURE DROP THROUGH THE CLEAN FILTER ELEMENT

The Pressure Drop through the filter element is related both to the internal diameter of the filter element and to the filter media; this value is affected by the oil viscosity in a roughly proportional way: e.g. when the  $\Delta p$  value from the curve is 0,2 bar and a 46 cSt oil is used, the corresponding value is 0,31 ( $=0,2 \times 46/30$ ) bar.


#### Element R-1-10




#### Element R-1-11




#### Element R-1-20



#### Element R-1-22



#### Element R-1-30



The above diagrams have been obtained at the FILTREC laboratory, according to the ISO 3968 specification, with mineral oil having 30 cSt viscosity and 0,86 Kg/dm<sup>3</sup> density.

In case of discrepancy, please check contamination level, viscosity and features of the oil in use and the sampling points of the differential pressure.

# Clogging indicator

The Pressure Drop ( $\Delta p$ ) through the filter increases during the system operation due to the contaminant retained by the filter element.




The filter element must be replaced when the indicator shows and before the  $\Delta p$  reaches the by-pass value setting.

N.B. in cold start conditions a false alarm can be caused by higher oil viscosity due to low temperature; the indicator alarm must be considered at normal working temperature only.

The clogging indicator registers the pressure upstream the filter element:

- in the VISUAL indicator the red area shows the need for element replacement.
- in the ELECTRIC indicator an electrical switch is activated.



## PRESSURE SWITCH



CODE	SETTING
R2	1,3 bar (18,9 psi) N.O.
R3	1,3 bar (18,9 psi) N.C.



- Current: 0,5 A resistive/ 0,2 A inductive
- Max voltage: 30-48 V DC
- Protection: IP54 as per DIN 40050

## VISUAL PRESSURE GAUGE



CODE	SETTING
R6	1,3 bar (18,9 psi)

## PRESSURE/ VACUUM GAUGE





CODE	SCALE
R7	0 ÷ 1,4 bar (0 ÷ 20 psi) green sector
	1,4 ÷ 5 bar (20 ÷ 72,5 psi) red sector

Housing in black ABS material


N.B. Multipurpose product: this gauge can also be used as vacuum gauge on suction filters.

## PRESSURE GAUGE



CODE	SCALE
R9	0 ÷ 1 bar (0 ÷ 14,5 psi) green sector
	1 ÷ 1,5 bar (14,5 ÷ 22 psi) yellow sector
	1,5 ÷ 4 bar (22 ÷ 58 psi) red sector

Housing in black ABS material




CODE	SCALE
R10	0 ÷ 1 bar (0 ÷ 14,5 psi) green sector
	1 ÷ 1,5 bar (14,5 ÷ 22 psi) yellow sector
	1,5 ÷ 4 bar (22 ÷ 58 psi) red sector

Housing in black ABS material

Preferential option

## User Tips



### FIXING BOLTS TIGHTENING TORQUE

M8	25 Nm
----	-------

### Installation

Make sure that the filter flange is well secured on the tank lid through the fixing holes and that the hose is properly connected to the IN port; verify that the OUT port is clear (in this port an extension tube can be fitted, so that the outlet is below the oil level).

After mounting verify that no tension is present on the filter.

Make sure that the air breather, if present, is in a protected position, that enough space is available for filter element replacement and that the clogging indicator is in a easily viewable position.

If an electrical indicator is used, make sure that it is properly wired.

We recommend the stocking of a spare FILTREC filter element for timely replacement when required.

### Operation

Make sure that the filter works within the conditions of pressure, temperature and fluid compatibility given in the first page of this data sheet. The filter element must be replaced as soon as the clogging indicator signals at working temperature (in cold start conditions, oil temperature lower than 30°C, a false alarm can be given due to oil viscosity). If no clogging indicator is mounted, make sure that the cartridge is replaced according to the system manufacturer's recommendations.

### Maintenance

Before removing the top cover, ensure that the system is switched off and there is no residual pressure in the filter.

Unscrew the top cover by turning it anti-clockwise and remove it. Remove the spring first and then the dirty filter element pulling it carefully. Clean the bowl and fit a new FILTREC element, verifying the part number, particularly concerning the micron rating. When fitting the new element, open the plastic protection on the top and insert the element over the spigot in the filter bowl, then remove completely the plastic protection.

Check the top cover gasket conditions and replace if necessary; put the spring in its position over the filter element and then screw the top cover by turning it clockwise, tighten until it stops.

N.B. The used filter elements cannot be cleaned and re-used.

### PED Compliance

FR-8 filters conform to PED 97/23/CE norm, article 3 section 3, and so they can be used with fluids of group 2 (liquids with steam pressure < 0,5 bar at the maximum allowable temperature, article 3, section 1.1(b) – sub-section II).

### WARNING

**Make sure that Personal Protective Equipment (PPE) is worn during installation and maintenance operation.**

### Disposal of filter elements

The used filter elements and the filter parts dirty of oil are classified as "Dangerous waste material": they must be disposed according to the local laws by authorized Companies.



**FR-8 series**

[www.filtrec.com](http://www.filtrec.com)

